

Component check sequence

- Engine management system - connections/wiring/relays
- Air intake system/vacuum system - leaks
- Engine coolant temperature (ECT) sensor
- Intake air temperature (IAT) sensor
- Condition of fuel/fuel filter
- Fuel pump/connections
- Fuel pressure/delivery rate/fuel pressure regulator
- Evaporative emission (EVAP) canister purge valve
- Injectors
- Heated oxygen sensor (HO2S)