


H29	ABS warning lamp
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
X1	Data link connector (DLC)
A16	Electronic control unit (ECU)
F	Fuse
FL	Fusible link
Y22	Hydraulic modulator
15	Ignition switch - ignition ON
A5	Instrument panel
M61	Pump motor
K100	Pump motor relay
K38	System relay
B19	Wheel speed sensor, left front
B21	Wheel speed sensor, left rear
B20	Wheel speed sensor, right front
B22	Wheel speed sensor, right rear



bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

