

Telephone:
 Fax:
 GST registration no.:

Name:	Manufacturer:	Peugeot
Address:	Model:	
	Year:	1997
Tel - Private:	Registration:	
Tel - Business:	Mileage:	
Tel - Mobile	Job number:	
	Date	

31	Battery -
30	Battery +
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
EP3	Earth point location 3
EP9	Earth point location 9
H5	Engine oil pressure warning lamp
S25	Engine oil pressure warning lamp switch
S371	Exhaust gas recirculation (EGR) load switch
Y28	Exhaust gas recirculation (EGR) solenoid
Y12	Fuel shut-off solenoid
F	Fuse
A104	Glow plug control module
S205	Glow plug engine coolant temperature switch
K22	Glow plug relay
H25	Glow plug warning lamp
R5	Glow plugs
15	Ignition switch - ignition ON
50	Ignition switch - start signal
A162	Immobilizer control module
B184	Immobilizer transponder
K268	Injection pump advance relay
Y131	Injection pump advance solenoid
A150	Injection pump assembly
A5	Instrument panel
X92	Shorting link connector

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to

Identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

