

Telephone:  
Fax:

31	Battery -
30	Battery +
S6	Combination switch
M27	Door mirror adjustment motor, driver
M28	Door mirror adjustment motor, passenger
S98	Door mirror adjustment switch
R26	Door mirror heater, driver
R27	Door mirror heater, passenger
EP10	Earth point location 10
EP11	Earth point location 11
EP12	Earth point location 12
EP5	Earth point location 5
EP7	Earth point location 7
EP9	Earth point location 9
F	Fuse
X28-I	Fuse box/relay plate, fascia
R2	Heated rear window
K13	Heated rear window relay
S30	Heated rear window switch
15	Ignition switch - ignition ON

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

**NOTE:** In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

